



Combinatorial Measurements of Polymer Craze Growth Using the Copper Grid Test Method

Kathryn L. Beers, Alfred J. Crosby and Alamgir Karim







COMBI Crazing

NIST
National Institute of
Standards and Technology




- COMBI thin films in the NCMC: gradients
- Polymer crystallization in thin films: iPS and PP
- Applying the Copper Grid Test to gradient thin films
- Composition gradients: filled polymer films
- Summary





Copper Grid Tests and Gradient Thin Films

Copper Grid
coated with
glassy polymer



- Isolate crazes in thin films
 - Well suited to gradients
- *Statistical population of equally strained cells in one sample*
- Copper plastically deforms to “lock-in” applied strain
- *Use microscopy to analyze craze and fracture microstructures*

Lauterwasser, B.D. and E.J. Kramer. “Microscopic mechanisms and mechanics of craze growth and fracture”, *Phil. Mag. A*, **39**, 4, 469-495, 1979.



Combinatorial Approach to Polymer Films: Gradients

NIST
National Institute of
Standards and Technology

Variables:


- Film thickness
- Temperature
- Crosslink density
- Chemical functionality
- Crystallinity
- Composition
- Surface Patterns

Properties:

- Confinement
- Surface energy
- Adhesion energy
- Toughness
- Biocompatibility
- Miscibility /
Phase separation
- Wettability

Polystyrene

$h \sim 40 - 120 \text{ nm}$




Poly(styrene-*b*-methyl methacrylate)

$h \sim 40 - 120 \text{ nm}$



Poly(vinyl cinnamate)


$h \sim 120 \text{ nm}$



UV →




Crystallization Kinetics



Viscoelastic effect:
As melt becomes more viscous,
spherulites form and rates slow
down.









Surface tension anisotropy:
Decrease in rate is observed in
blends and thinning films.





Crystallization Morphologies


NIST
National Institute of
Standards and Technology






Polyolefin Crystallization Projects



NIST
National Institute of
Standards and Technology



- Nucleating Agents in Polypropylene (M. Walker)
 - Temperature and composition gradients in the presence of 4-biphenyl carboxylic acid:



- Phase Separation vs. Crystallization (H. Wang)*
 - Poly(ethylene-co-hexene) / poly(ethylene-co-butene)
 - Temperature gradients



* Wang, H., Hobbie, E. K., Shimizu, K., Wang, G. Z. G., Kim, H. D. and Han, C. C., "Competing Kinetics in Simultaneously Crystallizing and Phase-separating Polymer Blends", **J. Chem. Phys.**, **116**, 7311 (2002).



Combi Areas for Craze and Fracture Studies

Materials Capabilities:


- *Thickness gradients*
 - *pS (tacticity)*
 - *pMMA*
- *Composition gradients*
 - *Silica particles in pS and pMMA matrices*
 - *Polymer blends*
 - *Plasticized films*
- *Temperature gradients*
 - *Crystallinity*
- *Crosslink-density gradients*

COMBI Tools:


- *Flow coating / Interferometry*
- *Composition changes from continuous sampling*
- *Image Analysis (IDL)*
 - *Fast and accurate*
 - *Consistent*
 - *New approaches to analysis!*
- *Chemical mapping with IR Microscopy*
- *Automated, gradient UV exposure*



Validation: Polystyrene



- Majority of literature: $h \geq 100 \text{ nm}$
- Shoulder and neck regions in thicker films (mid-rib)
- Perforated microstructure in thin films (as opposed to discrete fibrils)







Microstructure & Film Thickness

NIST
National Institute of
Standards and Technology


Atactic pS




$h = 78 \text{ nm}$



$h = 100 \text{ nm}$




$h = 112 \text{ nm}$




$h = 190 \text{ nm}$


Isotactic pS



$h = 77 \text{ nm}$



$h = 103 \text{ nm}$



$h = 115 \text{ nm}$


all images: 800 nm




HT Image Analysis

NIST
National Institute of
Standards and Technology

Manual
Measurements:




$h = 78$ nm



$h = 190$ nm



Automated
Measurements:





Craze Depth vs. Film Thickness

NIST
National Institute of
Standards and Technology




$$\text{Craze Depth} = 0.37h$$

$$\text{Craze Thickness} = .26h$$





Craze Depth at the Crack Tip

NIST
National Institute of
Standards and Technology



$h = 80 \text{ nm}$







Craze Depth at the Crack Tip

NIST
National Institute of
Standards and Technology

Reduction of Plastic Constraint in Thin Films







$h = 190$ nm



pMMA

NIST
National Institute of
Standards and Technology




Scale bars: 250 nm




Filled Polymers: Composition Gradients


NIST
National Institute of
Standards and Technology



1



2




3




Filled Polymers: Composition Gradients

NIST
National Institute of
Standards and Technology



Breakup of filler
aggregates inside
← craze

Small voids induced in perforated microstructure
by silica particles? →



250 nm



Summary

- The Copper Grid Test method has been successfully adapted to a combinatorial and high throughput experiment using gradient film preparation methods and automated image analysis.
- Use of gradient films and automated image analysis not only accelerates the pace of experimentation, but reduces uncertainty, and can foster creative new ways of looking at experimental data.
- Future Directions:
 - Particle tracking during craze formation in filled polymers
 - Developing temperature and crystallinity gradients

Acknowledgments

Chris Stafford
Mike Fasolka
Marlon Walker