

nScriptTM

Writing the Future

Jim Story, President

nScript, Inc.
5202 N. Richmond Hill Road
Stillwater, OK 74075
Phone: 405.533.5299
jbs@nscript.biz

April, 2004



The Company

nScriptTM

Company history

- *nScript* is a wholly owned subsidiary of Sciperio
- Sciperio, working with the US Government Defense Advanced Research Projects Agency (DARPA), developed precision dispensing technology
- In 2002 Sciperio started *nScript* to commercialize the technology
- 2003 *nScript* developed pump, pump controller and motion platform products
- First hardware sales in Q4, 2003

What do we do that is unique?

- Deposit small feature sizes
- Deposit patterns without the need for templates or masks
- Deposit on conformal (nonlinear) surfaces
- Deposit a wide range of viscosities (1 to 1 million cp)
- Gentle dispensing process
- OFFER THESE DISPENSING ABILITIES IN COMBINATION WITH COMPLETE AUTOMATED PLATFORMS AND SUPPORT SERVICES

What is small?

- Lines: less than 150 microns in width
 - Normally can deposit 75 micron width and 35 micron height
 - Have deposited 25 microns wide under special conditions
- Dots: Less than 200 microns in diameter
 - 100 micron diameter with good repeatability
 - 50 micron diameter has been achieved

25 microns = .001 inch. A human hair is about 75 microns




Applications

- Lines
 - Straight
 - Curved
 - Conformal
- Dots
 - Bumps
 - Lenses
 - Via fill
- Layers
 - Lines and Dots
- Blends (Gradients)
 - Active mixing
 - Passive mixing

Examples


Lines

Lines and patterns




- Small geometries
- Complex patterns (From CAD files)
- 75 microns (25 microns demonstrated)

Breakout Pad





Writing breakout pattern




Precision starts and stops

The key is the ability to start
and stop the flow with
precision control



Conductive low temperature ink on Kapton





Resistor pads and lines




Dispensing solder lines



Adhesive on glass




75 micron line onto a 250 micron diameter shaft



Conformal Dispensing

Surface premapped using nScript Smart Z product



Writing conformal lines

Dynamic height sensing – product in development stage

Sensing
location and
writing on a
fly's wing




Examples

Dots


100 micron dots with conductive ink

100 micron OD x 10 micron tall
(75 Pico liter)





Micro assays


- Gene, Protein, Cell, Tissue
- Bio-Adhesives : fibrin glue



Micro lenses




Gold pads



Dispensing solder balls




Via filling



Examples


Layers

Directly-Written transmitter components



916MHz, 50Ω
Stochastic Dipole
50% size reduction

“WCB”
Written Circuit Board
Sintered silver particles
on glass




20K resistors (two-left)
3K resistor (right)





Parallel Resonant
LC network (ESD shunt)

Multi-leaded Capacitors
100pF capacitor (left)
25pF capacitor (right)





Examples




Conductors
Resistors
Capacitors
Inductors
Adhesives
Actives
Polymers
Battery
Biology

Passive RLC components

400MHz Tuned RF Transformer




Equivalent Circuit




Passive RLC components



15nH two-turn inductor
Kapton substrate, 0.005"
0.150" diameter




1pF Microstrip Interdigitated capacitor, 0.005" Kapton Film Substrate



Resistor array on microscope slide




LC network designed for
shunt LC resonance at
1.1GHz




25pF Multi-leaded RF
bypass capacitor


Dual band GPS antenna on Kapton



Antenna with LC load & 0603 chip balun
Silver & dielectric on 0.005" Kapton film



Close-up of LC load. This capacitor was designed to be tuned by trimming with a femtosecond laser




Return loss test on Agilent 8753ES VNA



Silver applied to 5mil Kapton, bent into a 3/8" diameter cylinder

11 layer bio construction with multiple materials per layer




Examples


Blending and Gradients
(Active Mixing)

Active mixing

- Macro-scale (1 mm and up)
 - Gradient transition
 - Non-defined line transient
- Micro-scale (1 mm and below)
 - No line segregation
 - Continuous color gradient
 - Homogenous mixing



Active mixing deposition



Direct Writing Pattern with Gradient fills



- Motion Platforms
- Smart Pump System
- Smart Z System
- Process Development
- Contract Manufacturing (direct writing)


Motion platforms

Other configurations available – please contact nScript


- Model 3De - 300 – HP
 - 300mm x 300mm x 100mm
 - 1 micron repeatability
 - 300 mm/sec in x and y
 - 100 mm/sec in z
- Model 3De – 600 – HP
 - 600mm x 600mm x 300mm
 - 1 micron repeatability
 - 300mm/sec



Motion stages: 3DE – 300 - HP




Servo actuated precision pump



Valve operation

Computer controlled piston actuation.

Pumping Sequence



Smart Pump dispensing system




Dispensing problems addressed by the *nScript* systems

- Small feature sizes – Lines 50μm and larger
- Dots – 50μm and larger in diameter
- Uniform Start/Stop Eliminate puddles and irregular end points (“dairy queen effect” or bump at line termination)
- Uniform line width
- Uniform line Thickness
- Uniform dispensed volume
- When used in conjunction with the **Smart Z** axis, the system can write on conformal surfaces

Blending pump with three materials

(not released for production)





nScript™ 3De Technology

“Writing the Future”

**nScript, Inc.
5202 N. Richmond Hill Road
Stillwater, OK 74075
Phone: 405.533.5299**

