



# Investigating Crystallization in Thin Films using High Throughput Methodologies Isotactic Polystyrene

Kathryn L. Beers, Jack F. Douglas, Eric J. Amis and Alamgir Karim

National Institute of Standards and Technology Polymers Division

NIST Combinatorial Methods Center Kick-Off Meeting January 2002



### Semi-crystalline Polymer Thin Films



#### **Industrial Motivation:**

- Semicrystalline commodity materials (PP/PE, PLA, PC, PEG, ...)
- Effect control of mechanical and optical properties, conductivity and permeability

#### Scientific Issues:

- Cooperativity in chain folding and diffusion, lamellar thickening, fractionation
- Molecular self-assembly
- Control of pattern formation → molecular architecture

#### **Objectives:**

 Establish relevant length scales in model thin films for dominant forces influencing crystallization rate and morphology




### Amorphous / Semi-crystalline Polymer Blends



### PMMA/PEO Blends in Thin Films:

- •Crystallization patterns tuned through polymer composition
- •Competition with phase separation (below UCST) changes ε
- •High F<sub>PMMA</sub> leads to fractal dendrites (diffusion limited aggregation)



Ferreiro et al., Phys. Rev. E, submitted.



#### Modeling Morphologies



- Model simulations based on solidification in twodimensional fluid mixtures (Cu-Ni alloys)
- Varying ε, seaweed and dendrite structures are obtained
- No spherulitic (elasticity) or fractal morphologies to date



Phase-Field Simulated Hexagonal Dendrite (J. Warren)


J. A. Warren and W. J. Boettinger, Acta Metall. Mater., 1995, 43, 689.



#### Why Isotactic Polystyrene (ipS)?



- Substantial literature on the crystallization of ipS in bulk and thin films
- ipS crystallizes slowly and on timescales measurable by "high-throughput" optical microscopy




- high T<sub>g</sub>: Films quenched at room temperature
- Temperature stage spans T<sub>q</sub> to near T<sub>m</sub> (218 °C)



#### Flow Coating









### Combinatorial / High-throughput Polymer Crystallization




- Access to larger parameter space
- Faster
- Cheaper



- Potential to Investigate multiple parameters:
  - Under-cooling temperature
  - Film thickness
  - Nucleating agents
  - Surface energy gradients
  - Surface pattern gradients






#### Temperature Gradient Stage













#### **Optical Image Library**








#### Effects of T on Growth Rates, G








#### Effects of T on Growth Rates






J. Boon, et al., J. Poly. Sci. A-2, 1968, 6, 1791.



#### Effects of h on Growth Rates





COMBIIzumi

Dependence of rate on film thickness:


 $G(h) = G(\infty)(1-d/h)^*$ 

\*S. Sawamura, et al., J. Phys. Soc. Jpn., 1998, 67, 3338.



## Effects of T on Structure (h > 23 nm)





Scale Bars: 5 µm



#### Effects of h on Structure



 $T = 186^{\circ}C$ 

h = 24 nm


 $T = 186^{\circ}C$ 


h = 19 nm

T = 186°C


h = 15 nm








Scale Bars: 10 μm




#### Effects of T on Dendritic Structures






NIST Combinatorial Methods Center




#### **Structural Control Factors**







#### Viscoelastic Effect







#### Focusing on Target Areas: NSOM



Samples prepared on a shallow temperature gradient for short times can contain a narrow range of size and structures.





In collaboration with:

L. Goldner and M. Fasolka

Optical Technology Division


NIST




#### **NSOM Polarimetry**



Topology (from force feedback)



Dichroism (z-scale 0-4%)



Scale bars: 1 µm

L. Goldner and M. Fasolka, Optical Technology, NIST

Angle of Birefringence (z-scale 0-180°)



• NSOM polarimetry may provide insight into more complex optical activity for multiple crystal structures



#### Conclusions




- Crystal growth rates of isotactic polystyrene as a function of h and T on continuous gradient films agree with literature. G passes through a maximum near 180°C and decreases with h below 80 nm.
- Morphological transitions with T and h are similar to a recent publication. As h approaches R<sub>g</sub>, spherulites are replaced by hexagonal dendrites.
- First evidence of competition between surface tension anisotropy and viscoelastic effects in crystallization.



#### **Future Directions**



- New measurement techniques
  - Mechanical and optical properties of semi-crystalline films
  - Kinetics in faster crystallizing films
  - Access to continuous parameter space on film
  - Structural probes during crystal formation
- Development of new informatics techniques (image analysis)
- Extension to polymers, blends and parameters of interest
  - iPP, PEG, PLA
  - Nucleating agents, surface energy or pattern gradients



#### Acknowledgments



Vincent Ferrreiro
Jim Warren

Lori Goldner Michael Fasolka

Archie P. Smith Amit Sehgal Alfred Crosby

\$\$
National Research Council