



# Combinatorial Measurement of Polymer Craze Growth and Fracture

Kathryn L. Beers, Alfred J. Crosby Alamgir Karim and Eric J. Amis


National Institute of Standards and Technology
Materials Science and Engineering Laboratory
Polymers Division
Gaithersburg, MD



## Craze Growth and Fracture in Thin Films



- Toughness of polymer related to craze formation
- Decades of research history on crazing
- Heterogeneities in processing of thin films may play role in craze formation and fracture properties



Craze Fibrils (behind craze front)

Craze Front (Taylor Instability)




### The Copper Grid Test



 Lauterwasser, B.D. and E.J. Kramer. "Microscopic mechanisms and mechanics of craze growth and fracture", *Phil. Mag. A*, 39, 4, 469-495, 1979.

Copper Grid coated with glassy polymer



- •Isolate crazes in thin films
- •Statistical population of equally strained cells in one sample
- Copper plastically deforms to "lock-in" applied strain
- Use microscopy to analyze craze and fracture microstructures



## Combinatorial Approach to Polymer Thin Films (gradients)



#### Variables:

- •Film thickness
- Crosslink density
- Chemical functionality
- Crystallinity
- Blend composition
- Surface Patterns

#### Properties:

- Confinement
- Surface energy
- Adhesion energy
- Toughness
- Biocompatibility
- Miscibility / Phase separation
- Wettability

Poly(styrene-b-methyl methacrylate)


H ~ 40 -120 nm



Polystyrene H ~ 40 -120 nm




Poly(vinyl cinnamate)
H ~ 120 nm





### Craze Growth in Semi-Crystalline Thin Films: ipS










## Combinatorial Approach with the Copper Grid Experiment








OM 250 μm





American Physical Society Fall Meeting



### **AFM of Craze Tips**




In the early stages of craze growth, little difference is observed between tip structure in films above and below 100 nm thick.


**Tip images:** always into amorphous film, never in contact with any other structures



Mid-Section Images: Far away from tip and any evidence of change in cross section size




Scale bars: 100 nm





#### **AFM of Craze Mid-Section**









### Craze Depth and Roughness








3 % strain H ~ 50 nm

3 % strain H ~ 100 nm





#### Conclusions / Future Plans



- Demonstrated applicability of the gradient combinatorial approach and AFM analysis to studying craze growth and fracture in thin films
- Future plans include pre- and post-strain crystallization (second gradient) as well as gradients in crosslink density, and other gradient variables

Acknowledgments:
Paul Smith
Mike Fasolka
NRC (\$\$\$)

